

INSTALLATION INSTRUCTIONS

STM SINGLE TRIM MOUNTING (Rose Trim Only)

Optional Single Trim Mount (STM) Rose Trim Installation

Note: STM is intended for inside Rose prep only. STM is not compatible with 07 Rose Lever Trim.

1. Only prep holes for the trim on the inside of door.
2. Insert the STM Mounting Plate into mortise cut-out as shown.
3. Install the Lock into the mortise cut-out & fasten to door using screws.
4. Install the Inside Lever Assembly, replacing the standard Reversible Spring Cage with the STM Modified Spring Cage.

